

1. ADD DETECTOR TAPE AND TRACER WIRE TO ALL PIPE.

